

AY-x55

Anti-Vandal Piezoelectric PIN Reader

Installation and Programming Manual

Models:

AY-S55

AY-T55

AY-T55B



AY-S55



AY-T55



AY-T55B

ROSSLARE
SECURITY PRODUCTS

Copyright © 2013 by Rosslare. All rights reserved.

This manual and the information contained herein are proprietary to ROSSLARE ENTERPRISES LIMITED and/or its related companies and/or subsidiaries' (hereafter: "ROSSLARE"). Only ROSSLARE and its customers have the right to use the information.

No part of this manual may be re-produced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of ROSSLARE.

ROSSLARE owns patents and patent applications, trademarks, copyrights, or other intellectual property rights covering the subject matter in this manual.

TEXTS, IMAGES, AND ILLUSTRATIONS INCLUDING THEIR ARRANGEMENT IN THIS DOCUMENT ARE SUBJECT TO THE PROTECTION OF COPYRIGHT LAWS AND OTHER LEGAL RIGHTS WORLDWIDE. THEIR USE, REPRODUCTION, AND TRANSMITTAL TO THIRD PARTIES WITHOUT EXPRESS WRITTEN PERMISSION MAY RESULT IN LEGAL PROCEEDINGS.

The furnishing of this manual to any party does not give that party or any third party any license to these patents, trademarks, copyrights or other intellectual property rights, except as expressly provided in any written agreement of ROSSLARE.

ROSSLARE reserves the right to revise and change this document at any time, without being obliged to announce such revisions or changes beforehand or after the fact.

Table of Contents

1. Introduction	7
1.1 Key Features	7
1.2 Box Content	7
1.3 Ancillary Equipment	8
2. Technical Specifications	9
3. Installation	10
3.1 Mounting Instructions	10
3.2 Wiring Instructions	11
4. Functionality	12
4.1 Transmit Mode	12
4.2 Programming the AY-x55	12
4.2.1 Entering Programming Mode	13
4.2.2 Exiting Programming Mode	14
4.2.3 Selecting Keypad Transmission Format	14
4.2.4 Changing the Programming Code	20
4.2.5 Changing the Facility Code	21
4.3 Setting the Backlight	21
4.4 Return to Factory Default Settings	22
4.5 Replacing a Lost Programming Code	23
A. Limited Warranty	24

List of Figures

Figure 1: Drilling Mounting Holes	10
---	----

List of Tables

Table 1: Wiring Colors.....	11
Table 2: Reader Programming Menus.....	13
Table 3: Keypad Transmission Format Option Number	15

Notice and Disclaimer

This manual's sole purpose is to assist installers and/or users in the safe and efficient installation and usage of the system and/or product, and/or software described herein.

BEFORE ATTEMPTING TO INSTALL AND/OR USE THE SYSTEM, THE INSTALLER AND THE USER MUST READ THIS MANUAL AND BECOME FAMILIAR WITH ALL SAFETY REQUIREMENTS AND OPERATING PROCEDURES.

- The system must not be used for purposes other than those for which it was designed.
- The use of the software associated with the system and/or product, if applicable, is subject to the terms of the license provided as part of the purchase documents.
- ROSSLARE exclusive warranty and liability is limited to the warranty and liability statement provided in an appendix at the end of this document.
- This manual describes the maximum configuration of the system with the maximum number of functions, including future options. Therefore, not all functions described in this manual may be available in the specific system and/or product configuration you purchased.
- Incorrect operation or installation, or failure of the user to effectively maintain the system, relieves the manufacturer (and seller) from all or any responsibility for consequent noncompliance, damage, or injury.
- The text, images and graphics contained in the manual are for the purpose of illustration and reference only.
- All data contained herein subject to change without prior notice.
- In no event shall manufacturer be liable for any special, direct, indirect, incidental, consequential, exemplary or punitive damages (including, without limitation, any and all damages from business interruption, loss of profits or revenue, cost of capital or loss of use of any property or capital or injury).
- All graphics in this manual are for reference only, some deviation between the image(s) and the actual product may occur.
- All wiring diagrams are intended for reference only, the photograph or graphic of the PCB(s) are intended for clearer illustration and understanding of the product and may differ from the actual PCB(s).

1. Introduction

The AY-x55 Family is a series is a vandal resistant programmable piezoelectric reader family that includes the AY-S55, AY-T55 and AY-T55B models.

The AY-x55 supports multiple keypad formats providing a high level of compatibility and connectivity with host controllers. The keypad can be programmed to output eight different data formats.

1.1 Key Features

The key features for the AYC-Q65 are:

- Built-in high sensitivity piezoelectric keypad
- Programmable backlit keypad (AY-T55B only)
- Programmable keypad transmission format
- Built-in case and back tamper
- Tamper output and LED control Input
- Programmable Facility code
- Two tri-colored LEDs
- Internal buzzer provides audible interface feedback

1.2 Box Content

Before beginning, verify that all of the following is in the box. If anything is missing, please report the discrepancy to your nearest Rosslare office.

- AY-x55 access control unit
- Mounting template
- Installation kit
- Installation and operating instructions

1.3 Ancillary Equipment

The following equipment is required to complete your installation:

- Compatible host controller
- Power supply – 5 to 16 VDC (from a regulated power supply)

Rosslare accessories can be found on www.rosslaresecurity.com.

2. Technical Specifications

Electrical Characteristics

	AY-S55	AY-T55	AY-T55B
Power Supply	Linear type (recommended)		
Voltage Range	5 to 16 VDC		
Input Current	Standby: 30 mA Max: 120 mA	Standby: 30 mA Max: 120 mA	Standby: 90 mA Max: 180 mA
Tamper Output	Open collector, active low, max. sink current 32 mA		
LED Control Input	Dry contact, N.O.		

Environmental Characteristics

Operating Temp. Range	-31°C to 63°C (-25°F to 145°F)		
Operating Environment	Suitable for outdoor use (meets IP65)		
Operating Humidity Range	0 to 95% (non-condensing)		

Dimensions

Height x Width x Depth	150 x 42 x 27 mm (5.91 x 1.65 x 1.06 in.)	120 x 65 x 27 mm (4.72 x 2.56 x 1.06 in.)	120 x 65 x 27 mm (4.72 x 2.56 x 1.06 in.)
Weight	400 g (14.11 oz)	500 g (17.64 oz)	502 g (17.71 oz)

3. Installation


3.1 Mounting Instructions

Before starting, select the location to mount the unit. This location should be at shoulder height.

To mount the unit:

1. Drill holes into the back of the metal according to how you want to mount the AY-x55. For US Gang Box installation, there are two hole indicators on the back of the metal cover specifically aligned for the US Gang Box (marked as "A" in Figure 1). For a four-screw custom installation, there are four indicators on the back (marked as "B" in Figure 1).

Figure 1: Drilling Mounting Holes



2. Route the interface cable from the reader to the controller (see Section 3.2). A linear type power supply is recommended.
3. Screw the AY-x55 back cover to its mounting location.
4. Return the front cover of the AY-x55 to the mounted back plate.

5. Secure the front cover by using the supplied security screw in the installation kit. An L-shaped tool is provided for use when tightening the security screw.

3.2 Wiring Instructions

The reader is supplied with a 41-cm (16") pigtail, having a 6-conductor cable.

To connect the unit to the controller:

1. Prepare the unit's cable by cutting the cable jacket back 2.5 cm (1") and strip the wire 2.5 cm (1").
2. Prepare the controller cable by cutting the cable jacket back 2.5 cm (1") and strip the wire 2.5 cm (1").
3. Splice the unit's pigtail wires to the corresponding controller wires and cover each connection.

Refer to Table 1 and to the wiring diagrams provided on the following pages.

Table 1: Wiring Colors

Color	Output
Red	+VDC
Black	Ground
White	Data 1/Clock
Green	Data 0 / Data
Brown	LED Control
Purple	Tamper

4. If the tamper output is used, connect the purple wire to the correct input on the controller.
5. Trim and cover all unused conductors.

4. Functionality

This chapter explains how the functionality of the reader.

4.1 Transmit Mode

When the AY-x55 is in Transmit mode, it is ready to receive data from a presented proximity card or from an entered PIN code.

When the reader is in Transmit mode, the Transmit LED is red and the Program LED is off.



When a PIN entry is being transmitted, the Transmit LED flashes green.



Keyboard data can be sent via one of eight different keypad transmission formats (see Section 4.2.3).

4.2 Programming the AY-x55

Programming the AY-x55 is done solely via the unit's keypad driven Programming Menu System. During the AY-x55's manufacturing process, certain codes and settings are pre-programmed. These settings are called the default factory settings.

Table 2 shows the names of all the AY-x55 reader menus.

Default factory settings are marked by a "*" sign.

Table 2: Reader Programming Menus

Menu Description	Default
1 Selecting Keypad Transmission Format Single Key, Wiegand 6-Bit (Rosslare Format) Single Key, Wiegand 6-Bit with Nibble + Parity Bits Single Key, Wiegand 8-Bit, Nibbles Complemented 4 Keys Binary + Facility Code, Wiegand 26-Bit 1 to 5 Keys + Facility Code, Wiegand 26-Bit 6 Keys BCD and Parity Bits, Wiegand 26-Bit Single Key, 3x4 Matrix Keypad 1 to 8 Keys BCD, Clock & Data Single Key, Wiegand 4-Bit	*
3 Changing the Programming Code	1234
4 Changing the Facility Code	0
6 Backlight Options (AY-T55B only) Off On (default) Off until key press when on for 10 seconds Dimmed until key press when on for 10 seconds	*
0 Return to Factory Default Settings	

4.2.1 Entering Programming Mode

To reach the Programming Menu System, the AY-x55 must first be placed into Programming mode.


To enter Programming mode:

1. Press # 4 times.

The Transmit LED turns off and the Program LED turns red.

Transmit   Program
Red

2. Enter your 4-digit Programming code.



If the Programming code is valid, the door LED turns green and the unit enters Programming mode.

Transmit   Program
Green



- The factory 4-digit Programming code is 1234.
- If a Programming code is not entered within 30 seconds, the unit returns to Transmit mode

4.2.2 Exiting Programming Mode

To exit Programming mode:

1. Press **#** to exit the Programming mode at any time.

Transmit   Program
Red

 - You hear a long beep.
 - The Transmit LED turns red and the Program LED turns off.

This indicates that the unit has returned to Transmit mode.

Wrong entries may reset the reader back to Transmit mode.

While in Programming mode, if no key is pressed for 30 seconds, the unit exits Programming mode and returns to Transmit mode.

4.2.3 Selecting Keypad Transmission Format

The AY-x55 has eight different keypad transmission formats.

See Section 4.2.3.1 for more information on keypad transmission formats.

To select the appropriate keypad transmission format:

1. Enter Programming mode.

Transmit   Program
Green
2. Press **1** to enter Menu 1.



The Transmit LED turns red.

Transmit   Program
Red Green

- Enter the appropriate option number for the keypad transmission format that you wish to select.



When selecting Option 8, the Program LED turns orange, awaiting an additional key input to select the number of keys.

You hear three beeps.

The Program LED turns off and the Transmit LED turns red.

Transmit   Program
Red

If an incorrect option number is entered, a long beep is emitted the reader returns to Transmit mode, and the keypad transmission format remains unchanged.



- Only one keypad transmission format can be active at any one time.
- When using the keypad transmission format "1 to 8 keys BCD, Clock & Data" (Option 8), an additional input is required to specify the number of keys in the PIN code.

4.2.3.1 Keypad Transmission Format Option Number

Table 3 presents the eight different keypad transmission formats.

Table 3: Keypad Transmission Format Option Number

Keypad Transmission Format	Option Number
Single Key, Wiegand 6-Bit (Rosslare Format)	1*
Single Key, Wiegand 6-Bit with Nibble + Parity Bits	2
Single Key, Wiegand 8-Bit, Nibbles Complemented	3
4 Keys Binary + Facility Code, Wiegand 26-Bit	4
1 to 5 Keys + Facility Code, Wiegand 26-Bit	5
6 Keys BCD and Parity Bits, Wiegand 26-Bit	6
Single Key, 3x4 Matrix Keypad	7
1 to 8 Keys BCD, Clock & Data Single Key	8

* Option 1 is the default factory setting.

More information on each of the different keypad transmission formats is available on the following pages.

Option 1: Single Key, Wiegand 6-Bit (Rosslare Format)

Each key press immediately sends 4 bits with 2 parity bits added – even parity for the first 3 bits and odd parity for the last 3 bits.

0 = 1 1010 0 = "A" in Hexadecimal	6 = 1 0110 0
1 = 0 0001 0	7 = 1 0111 1
2 = 0 0010 0	8 = 1 1000 1
3 = 0 0011 1	9 = 1 1001 0
4 = 1 0100 1	☐ = 1 1011 1 = "B" in Hexadecimal
5 = 1 0101 0	# = 0 1100 1 = "C" in Hexadecimal

Option 2: Single Key, Wiegand 6-Bit Nibble and Parities

Each key press immediately sends 4 bits with 2 parity bits added – even parity for the first 3 bits and odd parity for the last 3 bits.

0 = 0 0000 1	6 = 1 0110 0
1 = 0 0001 0	7 = 1 0111 1
2 = 0 0010 0	8 = 1 1000 1
3 = 0 0011 1	9 = 1 1001 0
4 = 1 0100 1	☐ = 1 1010 0 = "A" in Hexadecimal
5 = 1 0101 0	# = 1 1011 1 = "B" in Hexadecimal

Option 3: Single Key, Wiegand 8-Bit Nibbles Complemented

This option inverts the most significant bits in the message leaving the least 4 significant bits as a Binary Coded Decimal (BCD) representation of the key. The host system receives an 8-bit message.

0 = 11110000	6 = 10010110
1 = 11100001	7 = 10000111
2 = 11010010	8 = 01111000
3 = 11000011	9 = 01101001
4 = 10110100	Ⓐ = 01011010 = "A" in Hexadecimal
5 = 10100101	# = 01001011 = "B" in Hexadecimal

Option 4: 4 Keys Binary + Facility Code, Wiegand 26-Bit

This option buffers 4 keys and outputs keypad data with a 3-digit Facility code like a standard 26-Bit card output.

The Facility code is set in Programming Menu number four and can be in the range 000 to 255. The factory default setting for the Facility code is 000 (see Section 4.2.5).

The keypad PIN code is 4-digit long and can range between 0000 and 9999. On the fourth key press of the 4-digit PIN code, the data is sent across the Wiegand Data lines as binary data in the same format as a 26-Bit Card.

If Ⓐ or # are pressed during PIN code entry, the keypad clears the PIN code entry buffer, generate a beep and is ready to receive a new 4-digit keypad PIN code.

If the entry of the 4-digit keypad PIN code is disrupted and no number key is pressed within 5 seconds, the keypad clears the PIN code entry buffer, generate a beep and is ready to receive a new 4-digit keypad PIN code.

(EP) FFFF FFFF AAAA AAAA AAAA AAAA (OP)

Where:

EP = Even parity for first 12 bits

OP = Odd parity for last 12 bits

F = 8-bit Facility code

A = 16-bit code generated from keyboard

Option 5: 1 to 5 Keys + Facility Code, Wiegand 26-Bit

Option 5 buffers up to 5 keys and outputs keypad data with a Facility code like a 26-Bit card output.

The Facility code is set in Programming Menu number four and can be in the range 000 to 255. The factory default setting for the Facility code is 000 (see Section 4.2.5).

The keypad PIN code can be one to five digits in length and can range between 1 and 65,535. When entering a keypad PIN code that is less than 5 digits in length, # must be pressed to signify the end of PIN code entry. For keypad PIN codes that are 5 digits in length, on the fifth key press of the 5-digit PIN code, the data is sent across the Wiegand Data lines as binary data in the same format as a 26-Bit Card.

If  is pressed during PIN code entry or a PIN code greater than 65,535 is entered, the keypad clears the PIN code entry buffer, generates a beep and is ready to receive a new 5-digit keypad PIN code.

If the entry of the 1- to 5-digit keypad PIN code is disrupted and a number key or # is not pressed within 5 seconds, the keypad clears the PIN code entry buffer, generates a medium length beep and is ready to receive a new 1- to 5-digit keypad PIN code.

(EP) FFFF FFFF AAAA AAAA AAAA AAAA (OP)

Where:

EP = Even parity for first 12 bits

OP = Odd parity for last 12 bits

F = 8-bit Facility code

A = 16-bit code generated from keyboard

Option 6: 6 Keys BCD and Parity Bits, Wiegand 26-Bit

Option 6 sends buffer of 6 keys, adds parity and sends a 26-Bit Binary BCD message. Each key is a 4-bit equivalent of the decimal number.

The keypad PIN code must be 6 key presses long. On the sixth key press of the 6-digit PIN code, the data is sent across the Wiegand Data lines as a BCD message.

If the entry of the 6-digit keypad PIN code is disrupted and no number key is pressed within 5 seconds, the keypad clears the PIN code entry

buffer, generates a medium length beep and is ready to receive a new 6-digit keypad PIN code.

(EP) AAAA BBBB CCCC DDDD EEEE FFFF (OP)

Where:

EP = Even parity for first 12 bits

OP = Odd parity for last 12 bits

A = The first key entered

D = Fourth key entered

B = Second key entered

E = Fifth key entered

C = Third key entered

F = Sixth key entered

Option 7: Single Key, 3x4 Matrix Keypad

This unique mode is intended to let the host controller scan the AY-x55 keypad while still keeping the proximity card readers Wiegand 26-Bit or Clock & Data formats active.

An optional interface board must be used between the AY-x55 and the host system. Each key press is immediately sent on DATA0 as an ASCII character at a baud rate of 9600 bits per second.

When a key is pressed DATA1 is pulled "low" until the key is released at which point DATA1 is set to "high". This allows the controller to detect the duration of the key press.

The MD-P64 interface unit outputs the data received to 7 outputs emulating a keyboard. The interface unit does not affect any data that it receives from the proximity reader whether it is Wiegand 26-Bit or Clock & Data.

Key pressed = ASCII Value

0 = '0' (0x30 hex)

6 = '6' (0x36 hex)

1 = '1' (0x31 hex)

7 = '7' (0x37 hex)

2 = '2' (0x32 hex)

8 = '8' (0x38 hex)

3 = '3' (0x33 hex)

9 = '9' (0x39 hex)

4 = '4' (0x34 hex)

* = '*' (0x2A hex)

5 = '5' (0x35 hex)

= '#' (0x23 hex)

Option 8: 1 to 8 Keys BCD, Clock & Data

Buffers up to 8 keys and outputs keypad data without a Facility code like standard Clock and Data card output.

The keypad PIN code can be one to eight digits in length. The PIN code length is selected while programming the reader for Option 8. The reader transmits the data when it receives the last key press of the PIN code. The data is sent across the two data output lines as binary data in Clock & Data format.

If **⏏** or **#** are pressed during PIN code entry, the keypad clears the PIN code entry buffer, generates a beep, and is ready to receive a new keypad PIN code.

If the entry of the digit keypad PIN code is disrupted and a number key or **#** is not pressed within 5 seconds, the keypad clears the PIN code entry buffer, generates a medium length beep, and is ready to receive a new keypad PIN code.



When using the keypad transmission format "1 to 8 keys BCD, Clock & Data" (Option 8) an additional input is required to specify the number of keys in the PIN code.

4.2.4 Changing the Programming Code

1. Enter Programming mode.

Transmit   Program
Green

2. Press **3** to enter Menu 3.

3

The Transmit LED turns red.

Transmit   Program
Red Green

3. Enter the new 4-digit code you wish to set as the Programming code.

? **?** **?** **?**

The system returns to Transmit mode.

- You hear three beeps.
- The Program LED turns off and the Transmit LED turns red.

Transmit   Program
Red



- The Programming code cannot be erased, meaning the code 0000 is invalid and does not erase the Programming code.
- The factory default 4-digit Programming code is 1234.

4.2.5 Changing the Facility Code

1. Enter Programming mode.

Transmit   Program
Green


2. Press **4** to enter Menu 4.



The Transmit LED turns red.

Transmit   Program
Red Green

3. Enter the new 3-digit code you wish to set as the Facility code.



The system returns to Transmit mode.

- You hear three beeps.
- The Program LED turns off and the Transmit LED turns red.

Transmit   Program
Red



- The Facility code can be in the range of 000 to 255.
- The default Facility code is 0.

4.3 Setting the Backlight

1. Enter Programming mode.

Transmit   Program
Green

2. Press **6** to enter Menu 6.



The Transmit LED turns red.

Transmit   Program
Red Green

3. Enter the appropriate option number for the backlight option that you wish to select:

- **0** for always off
- **1** for always on
- **2** for 10 sec. backlight after a key is pressed otherwise off
- **3** for 10 sec. backlight after a key is pressed otherwise dimmed

The system returns to Transmit mode.

- You hear three beeps.
- The Program LED turns off and the Transmit LED is red.

Transmit   Program
Red

4.4 Return to Factory Default Settings



You must be very careful before using this command! This erases the entire memory and return all codes to their factory default setting.

1. Enter Programming mode.

Transmit   Program
Green


2. Press **0** to enter Menu 0.



The Transmit and Program LEDs flash red.

Transmit   Program
Red Red

3. Enter your 4-digit programming code.



If the Programming code is valid, all memory is erased. You hear three beeps and the controller returns to Normal mode.

If the Programming code is invalid, you hear a long beep and the controller returns to Normal mode without erasing the memory of the controller.

4.5 Replacing a Lost Programming Code

In the event that the Programming code is forgotten, the AY-x55 can be reprogrammed in the field using the following instructions:

1. Remove power from the reader.
2. Activate tamper by removing the reader from the wall or removing the reader's case.
3. Apply power to the reader.
4. You now have 10 seconds to enter Programming mode using the factory default Programming code 1234.

A. Limited Warranty

The full ROSSLARE Limited Warranty Statement is available in the Quick Links section on the ROSSLARE website at www.rosslaresecurity.com.

Rosslare considers any use of this product as agreement to the Warranty Terms even if you do not review them.



AY-x55

Asia Pacific, Middle East, Africa

Rosslare Enterprises Ltd.

Kowloon Bay, Hong Kong

Tel: +852 2795-5630

Fax: +852 2795-1508

support.apac@rosslaresecurity.com

United States and Canada

Rosslare Security Products, Inc.

Southlake, TX, USA

Toll Free: +1-866-632-1101

Local: +1-817-305-0006

Fax: +1-817-305-0069

support.na@rosslaresecurity.com

Europe

Rosslare Israel Ltd.

Rosh HaAyin, Israel

Tel: +972 3 938-6838

Fax: +972 3 938-6830

support.eu@rosslaresecurity.com

Latin America

Rosslare Latin America

Buenos Aires, Argentina

Tel: +54-11-4001-3104

support.la@rosslaresecurity.com

China

Rosslare Electronics (Shenzhen) Ltd.

Shenzhen, China

Tel: +86 755 8610 6842

Fax: +86 755 8610 6101

support.cn@rosslaresecurity.com

India

Rosslare Electronics India Pvt Ltd.

Tel/Fax: +91 20 40147830

Mobile: +91 9975768824

sales.in@rosslaresecurity.com

ROSSLARE
SECURITY PRODUCTS
www.rosslaresecurity.com



0706-0960159+02